



Winter – Home Maintenance Tips

- ✓ Make sure all electrical holiday decorations have tight connections
- ✓ Prevent frozen pipes - If traveling for the holidays or concerned about frozen pipes, set faucets to run at a drip. Also, keep your thermostat at 55°F or above if you travel or go on vacation
- ✓ Vacuum refrigerator coils - Unplug the appliance before you begin.
- ✓ Maintain yard and exterior - Rake and remove leaves, shovel snow, and keep pathways and patios clear.



- ✓ Clean your gutters and drainpipes as needed
- ✓ Check the water hoses on the clothes washer, refrigerator icemaker and dishwasher for cracks and bubbles
- ✓ Test detectors and replace batteries